



**THAME**  
ENGINEERING

# SERRATION CLEANING PLATE



Serration plates are available in three standard types, each supplied in a wooden case with a tube of lapping paste.

- Allows quick and easy cleaning and deburring of serrated chuck jaws.
- Improved accuracy of mounting to base jaws.
- Extends the working life and precision of the top jaws.
- Keeps jaw serrations in perfect condition.
- Different serration type on reverse of plate.

Simply apply lapping paste and guide jaw onto serrations on plate, move jaw back and forth until serrations are in top condition.

THAME PART NO	SERRATION TYPE		
ES96	1/16" × 90°	and reverse	1.5mm × 60°
ES99	1/16" × 90°	" "	3/32" × 90°
ES66	1.5mm × 60°	" "	3mm × 60°